

## GEO 418 – „Hyperspectral Earth Observation“

[Martin.Bachmann@dlr.de](mailto:Martin.Bachmann@dlr.de)



# Field Spectroscopy

[martin.bachmann@dlr.de](mailto:martin.bachmann@dlr.de)  
[andreas.mueller@dlr.de](mailto:andreas.mueller@dlr.de)



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft



# Contents of Module

- Sampling
  - Geographic sampling strategies
  - Sampling strategies for RS (ground „truthing“)
- Theory of field spectroscopy
  - Physical basics & measurement principle
  - Instrumentation
  - Illumination
  - Post-Processing
  - Lab- Vs. field spectroscopy
- Practical issues of field spectroscopy
  - How to measure?
  - How to protocol?
- References






## Sampling Strategies




Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft


# Sampling Strategies




Random




Rectangular  
Sampling




Stratified




Stratified  
Random



Stratified  
Areal weighted



# Sampling Strategies for RS



Brogaard & Ólafsdóttir 1997




# Ground Cover Percentage – *Cabo de Gata*









# Ground Cover Percentage – *Cabo de Gata*



## Spatial distribution of:

-  **Vital vegetation**  
e.g. *Opuntia ficus-indica*,  
*Chamaerops humilis*
-  **Dry / dead vegetation**  
e.g. *Stipa tenacissima*,  
*S. capensis*
-  **Bare soil**  
e.g., Regosol,  
Leptosol

# Scale of spatial heterogeneity



**Spatial resolution**  
(pixel size) of HyMap data:  
5m x 5m

**Natural size**  
of vegetation & soil patches  
 $\ll 2 \text{ m}^2$





➤ Sampling of heterogeneous parameters

➤ Min. sampling area  $A = (\text{GSD} (1 + 2 * \Delta_{x,y}))^2$

➤  $\Delta_{x,y}$ : accuracy of georeferenzation


➤ GSD: Ground Sampling Distance

➤ GSD = 30m,  $\Delta_{x,y} = 2$  pix.       $A = 150 * 150 \text{m}$

➤ GSD = 30m,  $\Delta_{x,y} = 0.5$  pix.       $A = 60 * 60 \text{ m}$

➤ GSD = 10m,  $\Delta_{x,y} = 2$  pix.       $A = 50 * 50 \text{ m}$


➤ GSD = 10m,  $\Delta_{x,y} = 0.5$  pix.       $A = 20 * 20 \text{ m}$



Study area




- Min. number of subplots  $N = (\sigma t / a)^2$ 
  - $\sigma$ : standard deviation of sampled parameter
  - $t$ : Student's t-value
  - $a$ : required accuracy of sampled parameter



- Ground cover sampling with accuracy  $a$ :  $\pm 10\%$
- t-value = 2.3 (90% confidence )

➤ $\sigma = 0.07$	$N = 2$
➤ $\sigma = 0.09$	$N = 5$
➤ $\sigma = 0.19$	$N = 19$

Study area



# Example of spatial heterogeneity


- Field measurements for 10 representative sample sites at Cabo de Gata  
(long-term measurement installations by Uni Almeria)

- Various vegetation communities, soils, degradation status


## Field measurements 2004

Average ground cover, measured with 1m<sup>2</sup> frame.

Accuracy:  $\pm 10\%$  abundance absolut (literature)



10 sites



each with 20 - 70 subplots



## Field spectroscopy - Introduction




Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft



## ➤ Spectroscopy

... measurements based on the **interactions between electromagnetic radiation and materials** as a **function of wavelength**





# Spectroscopy

- General Application: material identification & quantification
  - Transmission spectroscopy widely applied in laboratory equipment
  - Analytical chemistry, biology, astronomy, ...
  
- Support for Remote Sensing
  - Calibration / validation of RS images (DN => at-sensor radiance)
  - Atmospheric correction (at-sensor radiance => reflectance)
  - Material identification in the field (“Spectral Geologist”)
  - Characterization of surface materials for image interpretation
  - Compilation of Spectral Libraries
  - Model development / quantitative information extraction
  - In-situ measurements of anomalies
  - ...



Milton 2007



# Field Spectroscopy





# Spectroscopy – Measuring with light

➤ The sensor measures:

**Radiance, At-Sensor Radiance  $L$  [ $\text{W m}^{-2} \text{sr}^{-1}$ ]**


=> Unit after system correction, described as L1 product




# Physical Basics

- Solid Angle  $\Omega$  (Raumwinkel) steradian = area / radius<sup>2</sup>
- Sphere =  $4\pi r^2 / r^2 = 4\pi$  [sr]
- Sky =  $2\pi$  [sr]

In 2-D:  
Radiant



In 3-D:  
Steradian





# Physical Basics

Measure should be:

- I. Independent of incoming radiation (power and geometry)
- II. Independent from atmospheric conditions
- III. Independent of sensor properties (instrument & detector characteristics)

=> Material property only !

But: at-sensor radiance  $L$  [ $\text{W m}^{-2} \text{sr}^{-1}$ ] still depends on (I, II, III)

Thus more suitable measure: **reflection  $\rho$  = % of reflected radiation**

- No unit, but [ % ]
- Independent from illumination & sensor
- (Almost) independent from geometry & atmosphere



# Measurement principle

**But:** sensors do measure radiance  $L = f(\text{sensor, illumination, ...})$

**We want:** % reflected

1. Measuring incoming and reflected radiance, then ratio:



$$\rho_{\text{target}} = L_{\text{target}} / L_{\text{reference}}$$

2. Commonly for higher precision the hemispherical radiation  $E$  is measured:

$$\rho_{\text{target}} = L_{\text{target}} * \pi / E$$

3. **If you use only one instrument:**  
**measure relative to known reference material**

$$\frac{L_{\text{Reference}}}{L_{\text{Target}}} = \frac{\rho_{\text{Reference}}}{\rho_{\text{Target}}}$$




$$\rho_{\text{target}} = (L_{\text{target}} / L_{\text{referenz}}) * \rho_{\text{referenz}}$$

$$\rho_{\text{target, Band 1}} = (L_{\text{target, Band 1}} / L_{\text{referenz, Band 1}}) * \rho_{\text{referenz, Band 1}}$$

$$\rho_{\text{target, Band 2}} = (L_{\text{target, Band 2}} / L_{\text{referenz, Band 2}}) * \rho_{\text{referenz, Band 2}}$$

$$\rho_{\text{target, Band 3}} = (L_{\text{target, Band 3}} / L_{\text{referenz, Band 3}}) * \rho_{\text{referenz, Band 3}}$$

$$\rho_{\text{target, Band n}} = (L_{\text{target, Band n}} / L_{\text{referenz, Band n}}) * \rho_{\text{referenz, Band n}}$$



# White Reference

## ➤ White reference $\rho_{\text{referenz}}$ :

### ➤ Desired material properties:


- 100% reflection for all wavelengths
- Lambertian (diffuse) reflection
- Highly opaque
- No fluorescent excitation for wavelengths longer than 300 nm
- Spatially uniform, cleanable, durable, and stable

## ➤ Used:


- Barium sulphate  $\text{BaSO}_4$ : cheap, but  $\rho$  not constant over longer time intervals (hygroscopic material)
- Polytetrafluoroethylene PTFE (Spektralon, Halon): best reflection standard, durable but expensive

# White Reference

TYPICAL 8 ° /HEMISPHERICAL REFLECTANCE- OPTICAL GRADE  
SPECTRALON




TYPICAL 8 ° /HEMISPHERICAL REFLECTANCE- SPACE-GRADE  
SPECTRALON




<http://www.labsphere.com/>
















Hemispherical



Directional

<i>Incoming/Reflected</i>	<b>Directional</b>	<b>Conical</b>	<b>Hemispherical</b>
<i>Directional</i>	<b>Bidirectional</b> Case 1 	<b>Directional-conical</b> Case 2 	<b>Directional-hemispherical</b> Case 3 
<i>Conical</i>	<b>Conical-directional</b> Case 4 	<b>Biconical</b> Case 5 	<b>Conical-hemispherical</b> Case 6 
<i>Hemispherical</i>	<b>Hemispherical-directional</b> Case 7 	<b>Hemispherical-conical</b> Case 8 	<b>Bihemispherical</b> Case 9 

**Schaepman-Strub 2006**





## Instrumentation




Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft



Common bundle carries: UV/VNIR fibers, SWIR 1 fibers, and SWIR 2 fibers



VNIR: Silicone photodiode detector array




SWIR 1+2: InGaAs detector





Name	FieldSpec® Pro VNIR	FieldSpec® Pro JR	FieldSpec® Pro FR
Spectral Range	350-1050 nm	350-2500 nm	350-2500 nm
Spectral Resolution	350-1050 nm	3 nm @ 700 nm 30 nm @ 1400 & 2100nm	3 nm @ 700 nm 10 nm @ 1400 & 2100nm
Sampling Interval	1.4 nm @ 350-1050 nm	1.4 nm @ 350-1050 nm 2 nm @ 1000-2500 nm	1.4 nm @ 350-1050 nm 2 nm @ 1000-2500 nm
Scanning time	Integration times = $2^n \times 17$ ms for $n = 0, 1, \dots, 15$	100 milliseconds	100 milliseconds
Detectors	One 512 element Si photodiode array 350-1000 nm	One 512 element Si photodiode array 350-1000 nm Two separate, TE cooled, graded index InGaAs photodiodes 1000-2500 nm	One 512 element Si photodiode array 350-1000 nm Two separate, TE cooled, graded index InGaAs photodiodes 1000-2500 nm
Input	1.4 m fiber optic (25° field of view) Optional foreoptics available	1.4 m fiber optic (25° field of view) Optional foreoptics available	1.4 m fiber optic (25° field of view) Optional foreoptics available
Calibration	Wavelength, reflectance, radiance*, irradiance*. All calibrations are NIST traceable (*radiometric calibrations are optional)		
Noise Equivalent Radiance (NeDL)	UVVNIR $3.7 \times 10^{-10}$ W/cm <sup>2</sup> /nm/sr @ 700nm	UVVNIR $2.8 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 700nm NIR $2.4 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 1400nm NIR $8.8 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 2100nm	UVVNIR $1.4 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 700nm NIR $2.4 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 1400nm NIR $8.8 \times 10^{-9}$ W/cm <sup>2</sup> /nm/sr @ 2100nm
Notebook Computer	Pentium processor, 800 MB hard disk, 16 MB Ram, 3.5" floppy disk drive, battery, AC power supply		
Weight	5.7 kg or 12.55 lbs	7.2 kg or 15.8 lbs	7.2 kg or 15.8 lbs



<http://www.asdi.com>

## 350nm to 2500nm

768

(1) 512 Si

(2) 256 InGaAs

350nm to ~1000nm

~1000nm to 2500nm

100 JOURNAL OF DOCUMENTATION

ip (selectable)

#### 4° standard

er optic

~4 kg

~4 hours

16 Bit

 $\pm 0.1 \text{ nm}$ 

0.5 s integ. Time

 $0.8 \times 10^{-9} \text{ W cm}^{-2} \text{ nm}^{-1} \text{ sr}^{-1}$  $1.5 \times 10^{-9} \text{ W cm}^{-2} \text{ nm}^{-1} \text{ sr}^{-1}$  $1.8 \times 10^{-9} \text{ W cm}^{-2} \text{ nm}^{-1} \text{ sr}^{-1}$  $1.5 \times 10^{-4} \text{ W cm}^{-2} \text{ nm}^{-1} \text{ sr}^{-1}$  $1.5 \times 10^{-4} \text{ W cm}^{-2} \text{ nm}^{-1} \text{ sr}^{-1}$ 

the following:

400nm:  $\pm 5\%$ 


400nm:  $\pm 5\%$   
700nm:  $\pm 4\%$

700nm:  $\pm 4\%$   
2200nm:  $\pm 7\%$



A large, industrial-grade microscope with a yellow body and black components. The body is labeled "GER 3700". It features a large black handle on top and a complex black mounting structure on the right side. The microscope is shown from a side-on perspective, highlighting its robust design.

split in 2  
companies,  
SpectraVista  
& S. Evolution



**Figure 3-48.** Comparison of the  $D^*$  of various infrared detectors when operated at the indicated temperature (Hudson, 1969).






„Extras“:

- Fiberoptics  
(FOV: SE: 25° / ASD: 25°)
- Forepotics for smaller FOV:  
(SE: 8°, 14° / ASD: 1°, 5°)
- Contact probes incl. illumination source (=> geol. applic.)
- „Cherry Picker“  
for canopy measurements
- Goniometer for BRDF-measurements



SPARC Campaign [www.esa.int](http://www.esa.int)  
RSL Zürich [www.geo.unizh.ch/rsl/](http://www.geo.unizh.ch/rsl/)

# Foreoptics & FOV



**ASD, Bare Fiber, FOV = 25°**


$$\tan(\text{FOV}/2) = d/2 / h$$

$$d \sim 0.44 * h$$

$$h = 0.5\text{m} \quad d = 0.22\text{m}$$

$$h = 1.0\text{m} \quad d = 0.44\text{m}$$

$$h = 1.5\text{m} \quad d = 0.67\text{m}$$



The figure above shows the available fields-of-view (FOV) for the FieldSpec® FR with an instrument fore optic height of 135 cm. The dashed circle represents the FOV of a non-ASD instrument with a fixed 3° FOV. The solid circles are for ASD's FieldSpec® FR. The largest circle is the FOV of the FieldSpec®'s standard built-in fiberoptic cable, with optional foreoptics providing 1°, 5°, 8°, or 18°. Fore optics covering approximately the same range of angular FOVs are available for the other FieldSpec® instruments.





# Spectroscopy - Equipment Pools

## ➤ Where to get spectrometers?

- DLR – OpAIRS (DFD + IMF)
  - 2\* ASD FieldSpec Pro, 1\* SVC HR-1024, 1\* GER 3700, D&P FTIR, Microtops, ...
  - <http://www.caf.dlr.de>
- NERC / U. Edinburgh
  - ASDs, SVCs, GERs, Microtops, ...
  - <http://fsf.nerc.ac.uk/>
- University of Zürich
  - ASDs, GERs, FIGOS, ...
  - <http://www.geo.unizh.ch/rs1>
- University of Würzburg, Jena, Trier, Munich, ...






# Illumination



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft



Every object is emitting **electro-magnetic radiation**  
**according to its temperature.**






Earth:

~300k average surface temp.

$L_{\text{max}}$  at  $10 \mu\text{m}$  ( $=10.000\text{nm}$ )

# Illumination sources



# Illumination sources – Influences in the field







Figure 1. The major sources of illumination. Note that it is possible to have several sources of light scattered off of surrounding objects, each with its own unique spectral distribution.

# Typical laboratory setup








# Typical laboratory setup




# Reflections on sampling dish



Glass petri dish



Coated with "3M Black"





## Additional influencing factors



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft

# Physical basics

## Reflection behaviour of surfaces




Figure 4.7 Reflectance characteristics of idealized surfaces.



# Physical Basics

## ➤ BRDF

$L_\lambda = \rho_\lambda E_\lambda (\cos \Theta) f_r$   $f_r$  = bidirectional distribution function  
for Lambertian surfaces.:  $\rho_\lambda = (L_\lambda \pi) / (E_\lambda \cos \Theta)$

## ➤ Shade due to surface roughness

## ➤ HotSpot-effect:

If view direction = illumination direction => no shade visible  
=> brighter & specular => no Lambertian





Fig. 2: Bidirectional reflectance effect on a grass lawn, observed under different viewing angles from a FIGOS mounted camera in the solar principal plane. Solar zenith angle is 35°, indicated with red arrows. The view directions are given in blue. The camera is operated in the manual modus keeping aperture, exposure time and focal length constant ( $k=16$ ,  $t=1/15$ ,  $f=135\text{mm}$ ).

# DAISEX-1999


FIGOS data

Barrax, Spain

ALFALFA



FIGOS (550 nm)




FIGOS (800 nm)

BRDF - signatures




Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft


# Sample orientation & BRDF effects



- Take 2-5 measurements
- Rotate the sample by steps of  $90^\circ$
- Measure again
- Rotate again
- ...



# BRDF effects








## Post-Processing



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft



Typical workflow for  
spectral library compilation



# Processing of Spectra

## ➤ Pre-Processing:

- Radiance to reflectance transformation
- Sensor drift correction
- Binning
- Smoothing & filtering
- Calculate convex hull & continuum removal
- Bad-band list
- Spectral resampling

## ➤ Analysis:

- Classify spectra (e.g., compare to spectral library)
- Identify characteristic features
- Parameterization of features





## Field / Laboratory Spectroscopy



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft





# Laboratory spectroscopy

## Advantages

- Independent of weather & daylight
- Stable, constant illumination source
- Fixed measurement setup

## Disadvantages

- Changed surface roughness & moisture
- Large objects (trees) ???



# Laboratory spectroscopy

How to measure in the lab:

- Illumination using zenith angle  $\sim 30^\circ$
- Pre-heat lamp (remember Planck's law)
- „Black“ surrounding!
- Distance lamp – material should be large, otherwise lamp heat would dry the sample
- Reduce surface roughness & BRDF effects: use 2 lamps, rotate samples by  $90^\circ$
- White Reference at least every 25 measurements



# Field spectroscopy

## Advantages:

- Natural surface conditions (roughness, moisture)

## Disadvantages:

- Motion of the sun
  - reduced measurement time (solar noon  $\pm$  2 h)
  - changing illumination geometry
- Light scattered by surrounding



# Field spectroscopy

## ➤ Measurements in the field

- Measure with high solar zenith angle (at solar noon  $\pm$  2 h )
- Azimuth angle to illumination  $\sim 90^\circ$
- Vegetation: keep distance to canopy  
or: close to single leaf
- GER ( $<$  FOV)  
~5 measurements with slightly changing view angle  
(geometrical oversampling)
- ASD ( $>$  FOV)  
~5 measurements with identical view angle (temporal oversampling)  
or: measure continuous transect






## Sources of error in the lab



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft

# Lamp- and Instrument-Drift





Now: How to measure?



Deutsches Zentrum  
für Luft- und Raumfahrt e.V.  
in der Helmholtz-Gemeinschaft





# How to measure

1. Get your gear ready:
  - Batteries reloaded?
  - Spectralon clean?
  - Spare batteries for laptop & spectrometer?
  - All safely packed?
2. Power on / warm up of spectrometer & lamps
  - Min. 15 min before 1st measurement
3. **First** connect running **ASD** to laptop, **then** power on **laptop**
4. Check laptop settings
  - White Reference mode?
  - Correct directory & base name?
  - Set DC, WR & spectra averaging to (25-) **50**
  - Correct foreoptics selected?





# How to measure

## 5. Optimization

- Whenever changes in illumination / instrument temperature

## 6. Dark Current (DC)

- Automatically retrieved during WR & Optimization

## 7. White Reference (WR)

- Wait for stable signal (2x screen refresh) before WR
- At least every 10 minutes / 25 measurements

## 8. Measurement

- Wait for stable signal (1x screen refresh)
- (Approx.) same geometric setup as WR measurement
- Number in display “plant.**008**” => the **next** measurement to be saved!


## 9. Quality Control

- When pointing at spectralon, are there steps, or deviations from 100% line ?

## 10. “Lifetime”: ~2-4 h for one ASD-battery



# How to measure




## Time:

- Solar noon  $\pm$  2 h (depends on season & latitude)

## Geometry:

- Orthogonal to the sun (no shade)
- Best: facing sun, measure in  $90^\circ$  sideward
- Distance to target ~ as to Spectralon during WhiteReference





# How to protocol your measurements

Common Metadata include:

- Location & description of site (lat, lon, alt, land cover)
- Time of measurement
- Sky conditions, meteorological data (air temp., humidity, aerosol optical thickness, water vapor, ...)
- Instrument parameters (instrument, serial-nr., last calibration)
- Measurement method (radiance / reflectance, averaging, ...)
- Sample description (e.g., degraded *Stipa tenacissima*, Soil Sample B-12)
- Measurement geometry at sample (off-nadir, height above sample, ...)
- But: may need adjustment to each application



## Section A – GENERAL INFORMATION

Project name:		Country:		Region:	
Calibration use:	Yes <input type="checkbox"/>	No <input type="checkbox"/>	Observer(s):		Date:
Latitude:	<input type="text"/>	Longitude:	<input type="text"/>	Altitude:	<input type="text"/> m
Environment description: <small>(Middle-european, mediterranean, arctic, desert, coastal, ...)</small>					
Weather description:					

Additional information:

## Section B – EQUIPMENT USED

Spectrometer:	ASD-DFD <input type="checkbox"/>	ASD-IMF <input type="checkbox"/>	Other <input type="checkbox"/>	Specify:	White stand.:	Spectralon A <input type="checkbox"/>	Spectralon B <input type="checkbox"/>
Fore optic:	1° <input type="checkbox"/>	3° <input type="checkbox"/>	5° <input type="checkbox"/>	8° <input type="checkbox"/>	18° <input type="checkbox"/>	Other: °	Bare fiber - FOV:
Light source:	Sun <input type="checkbox"/>	Reflectance probe <input type="checkbox"/>	Tripod <input type="checkbox"/>				

Additional information:

## Section C – TARGET INFORMATION

Rock <input type="checkbox"/>		Soil <input type="checkbox"/>		Vegetation <input type="checkbox"/>	
Igneous <input type="checkbox"/>		Soil type:		Specie:	
Sedimentary <input type="checkbox"/>		Soil colour:		Dry <input type="checkbox"/>	Growing <input type="checkbox"/>
Metamorphic <input type="checkbox"/>		Humus content:		Flowering <input type="checkbox"/>	
		Moisture:			
Mineral <input type="checkbox"/>		Water <input type="checkbox"/>		Other <input type="checkbox"/>	Specify:





Section D – MEASUREMENTS						
Type:	Radiance <input type="checkbox"/>	Reflectance <input type="checkbox"/>	DN <input type="checkbox"/>	Emissivity <input type="checkbox"/>	Additional information:	
Averaging:	Optimisation <input type="checkbox"/>	White reference <input type="checkbox"/>	Spectra <input type="checkbox"/>	<div></div>		
	Optimisation <input type="checkbox"/>	White reference <input type="checkbox"/>	Measurement height: <input type="text"/>			
ID	Name	Photo (tick or name)	Time	Additional	Check 100 %	WR
					<input type="checkbox"/>	<input type="checkbox"/>
					<input type="checkbox"/>	<input type="checkbox"/>
					<input type="checkbox"/>	<input type="checkbox"/>
					<input type="checkbox"/>	<input type="checkbox"/>
					<input type="checkbox"/>	<input type="checkbox"/>





# References

- Edward J. Milton, Michael E. Schaepman, Karen Anderson, Mathias Kneubühler, Nigel Fox (2007): Progress in field spectroscopy. Remote Sensing of Environment, 1-18,
- Schaepman-Strub, G.; Schaepman, M.E.; Painter, T.H.; Dangel, S.; Martonchik, J. (2006): Reflectance quantities in optical remote sensing - definitions and case studies. Remote Sensing of Environment 103 (1).
- Sara Brogaard and Rannveig Ólafsdóttir (1997): Ground-truths or Ground-lies? Environmental sampling for remote sensing application exemplified by vegetation cover data. Lund Electronic Reports in Physical Geography.
- Analytical Spectral Devices, Inc. (ASD, 1999): Technical Guide, 4th Ed.
- Heiner Barsch (Hrsg.) (2000): Arbeitsmethoden in Physiogeographie und Geoökologie. Perthes Geographie-Kolleg.